

Fishing CamX

路亚相机 Lure Camera

快速入门指南·物品清单

Quick Start Guide · Packing List



路亚相机主机
Lure Camera

1PCS



无线座充
Wireless desktop charger

1PCS



充电线
Charging cable

1PCS



浮力圈
Buoyancy ring

1PCS




资料包
Datagram


1PCS

充电 Charging

- 充电时必须关闭相机电源。
- The camera shall be turned off before charging.




① 充电器充电 Charging by the charger



② 电脑充电 Charging by the computer

开/关机与连接使用

Switch-On/Off & Connect & Operation



使用说明
Operating Instruction



www.chasing.com



CanFish APP

Fishing CamX

Cámara Lure

Guía de Inicio Rápido y Lista de Artículos



Máquina principal
de Cámara Lure

1PCS



Cargador de base
inalámbrico

1PCS



Cable de
carga

1PCS



Anillo de
flotabilidad

1PCS




Paquete de
información


1PCS

Carga

- Cargar mientras la cámara está apagada




① Carga por el cargador



② Carga por la computadora

Encendido/apagado y conexión para uso



Instrucciones de uso



www.chasing.com



CanFish APP